




## **Bendable Titanium 5**

**Size: 52-20-141 Total Width: 141mm**



**PD ruler (mm)**

### **Printing Directions:**

1. Save this file to your desktop
2. Open the file and print
3. Uncheck "scale" or "fit" and click "actual size" or "adjust scale to 100%"

### **Sizing Directions:**

Place your frame face-down on this printout to compare sizes

**or**

Use the ruler to measure your current frame's total width